


KINDER®
Valley

Bean Bag

IMPORTANT! KEEP FOR FUTURE
REFERENCE

KEY FEATURES:

- Removable, washable cover- can be washed at 40°C.



Dimensions(cm): (L)70cm x (W)50cm

Fabric Composition:
48% Cotton

**WARNING: RISK OF SUFFOCATION. DO NOT LEAVE A CHILD
UNATTENDED. NOT SUITABLE FOR SLEEPING.**

KEEP AWAY FROM FIRE AND FLAMES



Approx. measurements only. Sizes may vary.

Contact Us...

E sales@kinder-valley.com

T 0844 7744644 - Option 2

www.kinder-valley.com

ASSEMBLY:

To open/close the zip, with the aid of a paper clip, hook one end of the paper clip over the zip slider.

The slider has been removed for safety reasons.

WARNINGS:

WARNING - The zip puller has been removed for safety reasons, when the bean bag is in use ensure the zip is fully closed and the zip slide is not in view.

WARNING - The zip can be opened (for example when the cover needs to be removed for washing) with the aid of a paper clip by hooking one end of the paper clip over the zip slider.

WARNING - Do not use the product if any part is broken; torn or missing and use only spare parts approved by manufacturer.

WARNING - Be aware of the risk of open fire and other sources of strong heat, such as electric bar.